

## INSTALLATION INSTRUCTIONS FOR BMW 6 CYLINDER CARBON FIBER ENGINE COVER

\* These instructions apply for vehicles equipped with either the narrow or wide fuel rail covers

Please take the time to fully read over these instructions before attempting to install the engine covers. This will greatly speed up the installation process and minimize any difficulties you may encounter.

### Tools Required:

- Socket wrench with extensions and 10mm socket head
- Flat headed (slot) screwdriver
- Torx T27 socket tip or wrench (similar sized Allen head wrench will work)

### Kit includes:

- 1 – Carbon Fiber Engine Cover
- 1 – Carbon Fiber Fuel Rail Cover
- 4 – Rubber lined washers
- 2 – Domed Nuts
- 2 – Domed Bolts

## LABOUR ESTIMATE GUIDE

0.5 Hours

### Step 1:

Using a flat-head screwdriver, remove the 4 plastic covers that cover the fixing fasteners on the OEM plastic engine cover



### Step 2 (optional on some cars):

On some vehicles, to gain access to all 4 of the fasteners that hold both the engine cover and fuel rail in place, it will be necessary to remove the housing that holds the cabin air filter.

